



## VEHICLE PROTECTION YOU DESIGN

### YOU CHOOSE:

- Your coverage level.
- Your contract length.
- Your number of miles.
- Your deductible.

### OneWorld Coverage Levels

- 1 Powertrain Coverage
- 2 Powertrain Plus Coverage
- 3 Deluxe Coverage
- 4 Ultimate Coverage

### ESTIMATED REPAIR COSTS

COMPONENT	COST ESTIMATE*
Engine	\$6,442
Transmission	\$4,475
Brake System	\$2,458
Air Conditioning	\$1,160
Power Steering	\$1,639
Drive Axle	\$759
Timing Belt	\$400

\*Cost estimates may vary by vehicle make, model, and repair facility repair rates.

# OneWorld Features

- Multiple Time and Mileage Terms
- 24/7 Roadside Assistance
- Credit Card Claim Payments
- Fully Insured

Need more benefits?  
We've got you covered.



#### 24/7 ROADSIDE ASSISTANCE<sup>1</sup>

Includes towing, jumpstarts, fuel/fluid delivery, lockout assistance and flat tire changes. Available 24 hours, 7 days a week, 365 days a year. Up to \$150 for towing and \$50 for all other covered services per incident.



#### SUBSTITUTE TRANSPORTATION<sup>2</sup>


Covers the costs on substitute transportation up to \$40 per day/\$280 per repair, on any covered repair!



#### DISLOCATION BENEFIT<sup>2</sup>

Stranded away from home? Reimburse up to \$150 per day/maximum of 3 days for interruption during your trip when stranded more than 150 miles from home. \$450 maximum benefit during entire contract term.

1. Parts and fuel/fluids are your additional cost.
2. See Vehicle Service Contract for details on applicability, limitations and reimbursement limits.



Only First Guard OneWorld offers you the flexibility to choose the coverage plan, length of coverage, number of miles and deductible to fit your driving style and budget.

Whether you drive 5,000 or 50,000 miles a year, we've made it easy to select the coverage that is right for you.

A TRUSTED PARTNER OF



**Provider**  
First Administrative Services Corp.

**Administrator**  
First Guard Warranty Corp.  
First Guard Administrative Services (in Missouri)  
[PO Box 29210]  
[Austin, TX 78755]  
[800-332-7029]

This brochure includes a sample of coverages set forth in the Vehicle Service Contract. Coverage is subject to exclusions and limitations set forth in the vehicle service contract. The terms and conditions of the optional coverage offered and purchased may vary both from state to state and according to the program features chosen by you.

Rev. 07.2021



Flexible, Dependable & Affordable

Peace of mind  
for the road ahead

VEHICLE SERVICE CONTRACT

## OneWorld Powertrain Coverage

**ENGINE:** All internally lubricated components and: timing belt, timing gears, exhaust manifolds, turbo assembly, oil pan, seals and gaskets, piston, timing cover, engine mounts, intake manifold, turbo waste gate, flywheel, cylinder heads, factory installed supercharger, intercooler, timing chain, flex plate, turbo intercooler, crankshaft pulley, oil pump, supercharger assembly, valve covers, crankshaft, equipment drive shaft, engine oil reservoir, camshaft, engine oil reservoir pump, balance shaft and belt, engine block (but only if damaged as a direct result of a mechanical failure of a covered component), and rotary engine components including: rotor, bearings, apex seal and eccentric shaft, rotary housing piston rings, connecting rod bearings, crankshaft main bearings, camshaft bearings, cam followers, guides, tensioners, rocker arms, rocker shafts, rocker bushings, cylinder head valves, valve guides, valve lifters, valve springs, valve seals, valve retainers, valve seats, push rods, water pump, oil pump housing, harmonic balancer, timing chain cover, intake and exhaust manifolds, cam gear bolt, harmonic balancer bolt, and head bolts.

**MANUAL TRANSMISSION:** Transfer case components: all internally lubricated components and: transmission mounts, seals and gaskets, clutch master cylinder, clutch release cylinder, shift linkage, gears and shaft, hydraulic clutch lines and case (but only if damaged as a direct result of a mechanical failure of a covered component).

**AXLE ASSEMBLY:** (Front, Rear, Four-wheel and All-wheel drive) - All internally lubricated components and: propeller shaft, axles and bearings, constant velocity joints and boots, center support bearing, universal joints, seals and gaskets, locking hubs, viscous coupling, thrust washers, four-wheel drive actuator, differential cover, and drive axle housing (but only if damaged as a direct result of a mechanical failure of a covered component).

**AUTOMATIC TRANSMISSION:** (Transfer Case Components) - All internally lubricated components and: torque converter, shift linkage, vacuum modulator, seals and gaskets, solenoids, transmission mounts, flywheel/flex plate electronic shift control unit, transmission cooler, oil pan, slave/clutch master cylinder, pilot bearing, throw-out bearing, and case (but only if damaged as a direct result of a mechanical failure of a covered component).

## OneWorld Powertrain Plus Coverage

*Includes all components listed below - in addition to Powertrain coverages*

**ELECTRICAL:** Starter solenoid, manually operated switches, starter motor, wiper motor, power window motor/regulator alternator, voltage regulator; starter drive, engine compartment wiring harness; computerized timing control unit, electronic ignition module; crank angle sensor, knock sensor; ignition switch, ignition switch lock cylinder; washer pump and switch, stop lamp switch; headlamp switch, turn signal switch; heater/A/C blower speed switch, manual heater/A/C control head; horns, trailer brake wiring harness; auxiliary power supply wiring, exterior cab lighting; auxiliary fuel tank switching unit and switch, and o-2 sensors.

**BRAKE COMPONENTS:** Master cylinder, seals and gaskets disc brake calipers, brake line and tubes, load-sensing proportioning valve, brake booster, wheel cylinders, parking brake cable and proportioning valve. The following ABS parts are covered: electronic control processor, wheel speed sensors; hydraulic pump/motor assembly, pressure modulator valve/ isolation dump valve; and (cont'd next page)

**BRAKE COMPONENTS (CONT'D):** accumulator. The following parts are also covered: power brake cylinder, compensating valve, hydraulic control unit, hydraulic trailer brake assembly and its components.

**STEERING COMPONENTS:** Idler arm, pitman arm, steering dampener, steering column coupling, steering column shaft, relay rod, tie rod, power steering pump, steering column assembly and all internal parts contained within the steering box, rack and pinion gear, power steering hoses, steering knuckles, steering box and rack and pinion gear housings, power steering assist cylinder, power steering pump cooler; twin "i" beam & bushings, and steering travel stop. Rear Wheel Steering: Rear steering shaft and couplings, power cylinder and pump, electronic control unit/solenoid, phase control unit, stepper motor, steering box, control valve, rack, and tie rod ends.

**AIR CONDITIONING/HEATING:** Heat pump, condenser, compressor clutch assembly, evaporator, compressor and bearings. blower motor, pressure regulator assembly, heater control valve, receiver/dryer, A/C pressure switches, expansion valve and condenser fan and motor seals and gaskets, Air conditioning lines and hoses, idler pulley and idler pulley bearing, high/low compressor cut-off switch, expansion valve, and pressure cycling switch. The following parts are also covered if they are required in connection with the repair of a covered part listed above and only if they have failed: accumulator/receiver dryer, orifice tube, oil and refrigerant.

## OneWorld Deluxe Coverage

*Includes all components listed below - in addition to Powertrain Plus and Powertrain coverages*

**ELECTRICAL:** Starter solenoid, automatic-off headlamp system, power seat motors, cruise control, manually operated switches, electronic combination entry system (does not include transmitters and receivers for remote locks), power door locks, retractable headlamp motor, windshield washer pump, distributor, ignition coil, starter motor, power mirror defogger, headlamp washer, engine cooling fan motor, power mirror motor, circuit open relay, defogger relay, power antenna motor/mast assembly, antenna cord, compact disc player, graphic equalizer, radio tuner, stereo component amplifier, tape player, GPS/navigation system (does not include programming or updates), electric fuel pump assembly, sunroof motor, lamp failure indicator sensor, electronic instrument cluster, power window motor/regulator, wiper motor, clutch starter interlock system, body control module, convertible top motor, alternator, cruise control vacuum motor, automatic shoulder belt motor and switches, automatic temperature control module, anti-lock braking/traction control computer and sensors, voltage regulator, starter drive, engine compartment wiring harness, computerized timing control unit, electronic ignition module, crank angle sensor, knock sensor, manual heater/a.c. control head, horns, trailer brake wiring harness, auxiliary power supply wiring, exterior cab lighting, O-2 sensors transducer, servo and amplifier, powertrain control module, power mirror electronic control unit, electronically controlled transmission/transfer case electronically modulated suspension computer, engine control computer progressive power steering computer, steering sensor, tilt/telescoping steering computer, trip computer, traction control computer, variable induction system, vehicle security computers and sensor.

**SUSPENSION:** (Front and Rear) - Upper and lower control arms, steering knuckle, bearings and bushings, electronic modulated suspension actuator, control arm shafts, spindle support, lower ball joints, tie rod assemblies, radius arm, spindle, upper ball joints, torsion bars, stabilizer bar, links and bushings, struts, strut bearing (cont'd next page)

**SUSPENSION (CONT'D):** plates, spindle and spindle support, wheel bearings, pannard bar, track bar, suspension bumpers, leaf springs, leaf spring shackles and hardware, load assist shocks, shocks, load assist springs, and (Front and Rear) - coil springs. Variable Dampening Suspension: compressor, control module, dampening actuator, solenoid, struts, height sensor, and mode selector switch.

**COMPUTER AND ELECTRONICS:** Variable induction system, electronic ignition module, cruise control computer, cruise control module, tilt/telescoping steering computer, electronically modulated suspension computer, engine control computer, power control module, sunroof control computer, electronic instrument display computer, vehicles security computers and sensors, Power mirror electronic control unit, automatic shoulder belt computer, trip computer, progressive power steering computer, steering sensor, skid control/traction control computer, intrusion monitoring system, power seat computer, electronic fuel injection (EFI) computer, anti-lock braking system (ABS) computer and sensors and electronically controlled transmission/transfer case computer and sensors.

**FUEL SYSTEM:** Fuel pressure regulator, fuel injectors, air flow meter, carburetor, fuel tank, throttle body, diesel fuel injection pump, fuel sensors, fuel pump, electronic fuel injection system, vacuum pump, fuel tank sending unit, metal fuel delivery lines, and fuel tank switching unit/switch.

**COOLING SYSTEM:** Engine fan shroud, engine fan clutch, engine fan motor, seals and gaskets, engine fan, radiator, fan bracket subassembly, belt tensioner, radiator, heater core, thermostat, blower motor, hot water valve, engine oil cooler, cooler lines and fittings.

**ADDITIONAL COMPONENTS:** Accelerator pedal and/or bracket subassembly, accelerator pedal rod assembly, back door lock assembly, convertible roof hook, door handles, door lock cylinder, front and rear door lock assembly, front seat belt, glove compartment door lock cylinder, glove compartment door latch subassembly, hinges, hood lock assembly, hood lock control cable assembly, hood support assembly, rear seat belt, reclining seat back adjuster, removable roof lock handle, seat track assembly, shoulder belt guide rail assembly, sliding roof drive cable, sliding roof guide rail, tail gate lock assembly, tilt roof lock handle assembly.

## OneWorld Ultimate Coverage

*Includes all Deluxe, Powertrain Plus & Powertrain coverages*

Our highest level of coverage option. This exclusionary coverage plan offers the most comprehensive coverage for your new or used vehicle. Covers most mechanical breakdown components, except for coverage listed as excluded on your Vehicle Service Contract (VSC).<sup>3</sup>



## OneWorld Surcharged Coverages

**COMMERCIAL USE (MANDATORY IF APPLICABLE):** Includes vehicles used for farming or ranching, job activities, ride-share services, and delivery of goods or food.

**LIFT KIT (MANDATORY IF APPLICABLE):** Provides coverage for oversized/undersized tires, body lifts and suspension lifts that are installed by the dealer or dealer authorized facility at the time of vehicle sale.

**ENHANCED ELECTRICAL (OPTIONAL):** Included in Deluxe and Ultimate Coverages

**TECHNOLOGY PACKAGE (OPTIONAL):** Included in Ultimate Coverage. Provides coverage for specified advanced technology items such as GPS/navigation system, factory Installed TV/VCR/DVD players.

**HYBRID ELECTRICAL VEHICLE COVERAGE (OPTIONAL):** Included with Ultimate Coverage. Provides coverage for components specific to Hybrid Electric Vehicles as listed in the Vehicle Service Contract.

**EMISSIONS COVERAGE (OPTIONAL):** Included in Ultimate Coverage. Provides coverage for vapor and emission canisters; positive crankcase ventilation valve; distributor cap and rotor; and exhaust systems.

**SAFETY RESTRAINT SYSTEM (OPTIONAL):** Included with Ultimate Coverage. Provides coverage for specified components such as airbags, impact sensors, clock springs, safety belts.

*Parts listed under Surcharged Coverages may not be inclusive, see Vehicle Service Contract for details.*

Certain restrictions apply for Commercial Use and Lift Kit Coverages. See Vehicle Service Contract for complete details.

### MULTIPLE DEDUCTIBLE CHOICES AVAILABLE

### EXAMPLES OF WHAT IS NOT COVERED

- Maintenance services including but not limited to: alignments, adjustments, tune-ups, brake pads.
- Damage or breakdown resulting from collision.
- Breakdowns covered by an insurance policy or manufacturer's major component or full coverage warranties
- Breakdowns when the manufacturer has announced it's responsibility through recall.
- For coverage types other than Ultimate, any part that is not specifically listed in the Schedule of Coverages.
- For a list of parts excluded under the Ultimate coverage, please refer to a sample copy of the Vehicle Service Contract for terms and conditions provided by your dealer.

*This is not a Vehicle Service Contract. The content of this brochure is limited by its size. The entire terms and exclusions of the agreement are included in the Vehicle Service Contract.*

3. See VSC for detailed coverage information.